

cleaning & maintenance information

morleys uPVC stairnosings

To achieve the most favourable performance, please follow the maintenance instructions below.

- 1.) Regular maintenance of the stairnosings will help prolong the life of the product. A build up of dirt and grease can prove hazardous and also affect the appearance of the profile.
- 2.) Firstly, any excess dirt should be removed by using a quality vacuum cleaner or a soft bristle brush. A harsh bristle will mark the uPVC.
- 3.) The uPVC should then be cleaned by using a soapless, neutral detergent in warm water on a damp cloth. They should then be rinsed with clean water, again using a soft, damp cloth.
- 4.) Polishes will reduce anti-slip properties and solvent cleaners are not suitable.
- 5.) Wet stairnosings are hazardous, therefore if the nosings are damp after cleaning, the area should be cordoned off until dry.

PVC Inserts

- 1.) A build up of dirt and grease will reduce the anti-slip properties of the insert.
- 2.) Polishes, sealants or any other coatings should not be applied to PVC inserts, as they too will reduce the anti-slip properties of the insert.
- 3.) PVC inserts and uPVC channels can be cleaned with a mild detergent diluted with water on a slightly damp cloth, then wiped dry with a clean cloth.
- 4.) Strong detergents must not be used on stairnosing inserts as this may cause fading of the insert colour.
- 5.) In the event of excessive build up of dirt & grease, a gentle rub down of the insert with a lightweight scourer will reproduce a key to the surface.